



1. P-Iris Interface
2. RJ-45 port
3. Power port
4. Reset
5. Micro-SD card
6. Video out
7. GND
8. ALARM RS485
9. AUDIO OUT
10. AUDIO IN
11. RESET